

WOOD CORBEL KITS | Lange Hood Corbel



RANG HOOD CORBEL INSTALLATION INSTRUCTIONS

Installation Considerations

Every successful installation begins with good planning and action. Do not wait until the last minute to order your supports, fasteners or adhesives for installation. Make sure that all aspects of the Range Hood Corbels are considered and discussed to ensure that your installation will be smooth and that your support products will be sufficient.

Note: that this installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation.

Characteristics of the Range Hood Corbels

Federal Brace Range Hood Corbels come as a kit that includes the selected corbel, the revolutionary mounting system and the fasteners required to install your range hood corbels. The corbel will come pre-routed for the converter to be installed. The revolutionary ribbed L bracket and sleeves make installation a snap.

The ribbed L bracket and sleeves are powdercoated gloss black and have ¼" holes in the down flange for mounting to the wall. The sleeves have two .18" holes for attaching to the corbel. The ribbed L bracket should be mounted to the wall so that it will be flush with the bottom of the

range hood when installed. The rib provides the weight bearing support needed for the hood. You will receive two sleeves for the corbel, one to be mounted toward the front of the corbel and one to be mounted toward the back. Once the sleeves are in place, the corbel simply slides over the plate on the L bracket and is secure. Small 3m adhesive square are provided if you desire to secure the bottom of the corbel to the wall.

Considerations when Installing Range Hood Corbels

Whenever installing the Range Hood Corbels be sure you are installing the ribbed L bracket into a stud or a minimum of 1.75" thick material. You will want the fasteners to have as much biting material as possible. This will provide a secure fastening of the brackets. Remember a weak support makes for a weak installation. Once your Range Hood Corbels are in place you will want to wipe them down to get rid of any hand prints or other debris.

Final step is to enjoy your work and your new kitchen counter! We are thankful that you chose to use Federal

www.federalbrace.com (877) 353-8899

Brace support brackets. Please send us images of your installation. We would love to add your work to our gallery to see Federal Brace at work.

Also, know that the highest compliment Federal Brace can be given is a reference from our customers to friends and family. If you have enjoyed your buying experience with Federal Brace please let someone know.



For any questions or comments please to contact us by email at customerservice@federalbrace.com or by phone at (877) 353-8899. If you are a visual learner, check out our installation videos on our YouTube channel Don't forget to share your projects with your new Federal Brace brackets on Twitter and Instagram, just tag us @FederalBrace. Like us on Facebook, and check out our boards on Pinterest for more home improvement/decor and DIY project ideas.















www.federalbrace.com (877) 353-8899