

# WOOD APPLIQUES & ONLAYS

## SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear proper protective gear.

Follow fixture, power tools, paint manufacturers' instructions, and users manuals.

Use common sense and follow good construction practices.

### TOOL & MATERIAL CHECKLIST

- Wood Glue
- Nail Gun
- Finishing Nails
- Extra Fine Sandpaper
- Putty Knife

### SPECIAL INSTRUCTIONS AND NOTES

- It is highly recommended that you paint/finish our appliques before you install them. Once installed, you can apply any necessary touch-up paint/finish.
- Clean installation surface and back of appliques of all dirt and dust with a clean cloth or sponge.
- Make sure that the surface and the back of the applique are completely dry before attempting installation.
- Measure and mark the location where the applique is going to be installed.

### STEP BY STEP INSTRUCTIONS

1. Lay the applique face down on a soft surface that will not scratch/dent the applique detail.
2. Apply a 1/2" bead of glue all the way around the back edge of the applique.
3. When pressing the applique up against the surface, some glue will seep out. Smooth excess caulk around the applique with a finger or the putty knife and apply extra glue that is needed to fill in any gaps.
4. Wipe off any excess adhesive caulk with a sponge or damp rag.
5. Larger appliques will need to be installed with nails in addition to the adhesive.

### EXAMPLE INSTALLATION DIAGRAMS

