

# All-Weather Door INSTALLATION INSTRUCTIONS

## Tools Required for Installation

**Hammer and Awl (or Nail) • Drill and 3/8" (1cm) Drill Bit • Sabre Saw • Phillips Screwdriver • Wear Safety Goggles**

- 1. Determine template placement** - The die-cut template is located in the center of pet door (in box). Remove screws holding the frame together; lift out template. Center template (width) in middle of door; tape in place. Position the top of the template 2" (5.1cm) taller than your pet's shoulder.  
**Important: Under no circumstances should the bottom edge of the rough opening be less than 3" (7.6cm) from the bottom edge of the wood door.**
- 2. Outline pet door opening** - With template taped in place, use a pencil to draw around the inside edge of template onto door. Use a nail or awl to mark outer screw holes.
- 3. Drilling holes - Next:** Drill the four (4) 3/8" (1cm) diameter outer screw holes.
- 4. Cutting the opening** - Mark and drill four (4) 3/8" (1cm) diameter inside saw-out starter holes. Begin with one of the inside 3/8" (1cm) corner holes. Using a sabre saw, cut along inside edge pencil line.
- 5. Assembly and adjustments (see diagram)** - Insert outer frame **(A)** into opening from exterior side (frame must be flush with door surface). Place inner frame **(B)** into opening from inside door and hold in place. Install screws **(C)** and tighten until snug. **Do not over-tighten.**
- 6. Locking your pet door** - Slide self-locking cover **(D)** into guide channel.

**All Weather Dog Door Wall Installation Kit** - The All Weather Door can also be installed in walls 4 3/4" - 7 1/4" (12.1cm - 18.4cm) using the optional Wall Installation Kit available from your retailer.

**As with any home improvement project, if you do not have the tools or skills to properly install your pet door, we suggest using a professional handyman or licensed contractor.**

