

# Armstrong® S-403 Excelon Floor Polish

## Use and Care

### Use For:

- All Armstrong commercial vinyl floor coverings **except** Safeguard, Safeguard Spa, Safeguard Design, Safeguard Hydro and Excelon SDT
- Asphalt and rubber tile
- Linoleum
- Ceramic - although not of much value on glazed ceramic
- Slate, terrazzo, concrete and brick although other products are designed for better results

Do Not Use For: Wood and marble

### **FLOOR PREP - FIRST COAT:**

- Strip floor using any high quality stripper designed for vinyl floor coverings
- Rinse thoroughly
- Let floor dry

### **FLOOR PREP - RECOATING:**

- Sweep or vacuum thoroughly
- Scrub with Armstrong Excelon Floor Cleaner (S-401)
- Rinse thoroughly
- Let floor dry

### **POLISH - LOW TRAFFIC:**

- Apply 3 to 5 coats (do not apply more than four coats of polish at one time; wait a minimum of 24 hours before applying more polish)
- Pour polish into a clean bucket (never pour polish directly onto floor)
- Use a clean finish mop (rayon) or finish applicator
- Let dry 30 minutes between coats

### **POLISH - HIGH TRAFFIC:**

- Follow instructions above for Low Traffic; then
- High speed burnish

OR

- Spray buff (spray-buff solution one part S-403 to two parts water)

OR

- Apply 1 or 2 extra coats