

K-T130, K-T132, K-T134 ANTIQUE™ BATH AND SHOWER FAUCET TRIM

Product Information

Applicable faucet trim only:	
Bath and shower six-prong handle*	K-T130-3D
Bath and shower lever handle*	K-T130-4D
Bath and shower oval handle*	K-T130-9B
Shower six-prong handle*	K-T132-3D
Shower lever handle*	K-T132-4D
Shower oval handle*	K-T132-9B
Valve six-prong handle*	K-T134-3D
Valve lever handle*	K-T134-4D

*	Rite-Temp _®	valve	must	be	ordered	to	complete fauc	et.
---	------------------------	-------	------	----	---------	----	---------------	-----

Required Accessories:	
Rite-Temp _® valve without stops OR	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
Ceramic dial faceplate (For -3D and -4D)	K-146
Ceramic dial faceplate and oval handle insert (For -9B)	K-262

^{*} For a complete listing of all the RiteTemp valves, refer to the K-304-* Specification Sheet or Roughing-In Sheet.

Optional Accessories:	
Large lever insert, single	K-9639
Large lever insert, single	K-9659
Deep roughing-in kit for K-304 valve (six-prong and artist edition handles)	58221
Deep roughing-in kit for K-304 valve (lever handles)	58222
HiFlow Rite-Temp _® thin wall installation kit	88526

Installation Notes

Install this product according to the installation guide.

NOTICE: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet.

Install straight pipe or tube drop of $7^{\prime\prime}$ (17.8 cm) to $18^{\prime\prime}$ (45.7 cm) with single elbow between valve and wall-mount spout.



