

KOHLER® Roughing-In

K-T10274, K-T10275 FORTE® RITE-TEMP® PRESSURE-BALANCING BATH AND SHOWER VALVE TRIM

Product Information

| Applicable products: | |
|--|-------------|
| Bath/shower trim, sculpted lever handle, NPT spout | K-T10274-4 |
| Bath/shower trim, traditional lever handle, NPT spout | K-T10274-4A |
| Bath/shower trim, sculpted lever handle, slip-fit spout | K-T10275-4 |
| Bath/shower trim, traditional lever handle, slip-fit spout | K-T10275-4A |
| Rite-Temp® valve must be ordered to complete faucet. | |

| Required accessories: | |
|--|-----------|
| Rite-Temp® valve OR | K-304-* |
| HiFlow Rite-Temp valve with stops | K-2971-KS |
| * For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In sheet. | |

| Optional accessories: | |
|--|---------|
| HiFlow Rite-Temp® thin wall installation kit | 88526 |
| Forte® deep roughing-in kit for Rite-Temp® valve (lever handles) | 1025388 |

Installation Notes

Install this product according to the installation guide.

Install the Rite-Temp® valve according to the valve installation guide.

NOTICE: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout.

