KOHLER Roughing-In

K-18485, K-T18488, K-T18489, K-T18490 SYMBOL™ BATH AND SHOWER FAUCET TRIM

Product Information

Installation Notes

Install this product according to the installation guide. **NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Appliachla product:			
Applicable product: Bath spout	K.	K-18485	
Bath and shower trim	-	K-T18488-4	
	-	K-T18489-4	
Shower trim			
Valve trim	K-	K-T18490-4	
Required accessories:			
Rite-Temp valve OR	K-304-*		
HiFlow Rite-Temp valve with stops OR	K-2	K-2971-KS	
Rite-Temp valve with diverter OR	K-1	K-11748-K	
Rite-Temp valve with diverter and stops	K-1	K-11748-KS	
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In Sheet.			
Optional accessories:			
HiFlow Rite-Temp _® thin wall installation kit		88526	



