

SPRAY CAN KIT INSTRUCTIONS

For BSP Model Series Kits

IMPORTANT:

Please read through the instructions carefully before starting project

Supplies Included

- 16oz Aerosolized Paint Cans (2)
- Comfort Hand Grip
- Instructions

Recommended Supplies (Not Included)

- TSP/Comet®/Ajax®
- Protective Surface Coverings
- Blue Painters Tape
- Paper Towels & Tack Cloth
- Razor Blade or Scrapers
- Latex/Rubber Gloves
- Steel Wool/Sandpaper (120 grit)
- Hair Dryer or Wet-Vacuum
- Ventilator Fan
- Respirator, & Protective Eyewear
- 100% Silicone Caulk
- Garbage Bag
- Any additional materials you may feel necessary depending on your situation

For all cast iron, steel, & ceramic fixtures - **Bathworks® EZ Etch Kit** is strongly recommended.

If unsure, do not paint, and return kit unopened.

For more recommended tools & supplies - visit: www.bath-works.net

Coverage

- 120 sq ft per kit
- 2 coats per application.

	Bathtub Only	Bathtub & 6' Surround
	# of Kits Needed	# of Kits Needed
Standard Tub	1	2
Large Tub	2	2
Corner Tub	2	3

Safety & Clean Up

Liquid products found within this kit are **solvent-borne** and are **highly flammable**. Care should be taken to avoid the inhalation of spray mist or vapors, as well as contact between the wet paint and exposed skin or eyes. Always keep work areas well ventilated and wear **personal protective equipment - respirator, eyewear, & gloves**. Keep away from flame, children, animals, and individuals sensitive to fumes. **Always ensure nearby surfaces are covered and protected**. Cleaning solvent for this paint is **Xylene** or a similar substitute. In the event of spills, ensure that Xylene is appropriate and safe to use on intended surfaces as there's a risk of serious and permanent damage to surfaces such as linoleum, plastics, wood and anything previously painted. See additional **safety notes** at the end of this document.

Directions

NOTE: *This kit may be used for bathtubs, tile, wall surrounds, sinks, & more!*

STEP 1: Clear the fixture and surrounding area of all personal items. Make sure there is positive air-flow and adequate ventilation in the work areas at all times.

CLEAN TUB THOROUGHLY! Scrub bathtub with Ajax® or Comet® while focusing on areas with heavy soap buildup - use steel wool if needed.

NOTE: ANY soap residue present may prevent bonding and cause failure.

OPTIONAL: *Use a razor blade or sharp scraper to remove the caulk around the surface that will be refinished. You may or may not elect to do this dependent upon individual situations. Not necessary, but recommended.*

STEP 2: With a single edge razor blade, scrape down the surface thoroughly. Keep special attention to areas under the soap tray and drain area. Wipe all scrapings and foreign materials into a trash bag. Keep this bag for debris nearby while working on this project.

NOTE: NEVER place tools or scrapers directly on unprotected surfaces such as toilet seat covers, counter tops, or linoleum floors.

STEP 3: Wear protective gloves and eyewear. Using TSP, Comet®, or Ajax® - mix with enough warm water to make a paste and apply over the entire surface. Scrub the surfaces thoroughly with Scotch-Brite® pad or sponge with the cleaning mixture.

STEP 4: Rinse the surface well after scrubbing. Water may be used from the bathtub or a bucket of water. While the bathtub or walls are still damp, sand the surface entirely using 120 grit sandpaper. Rinse well after.

STEP 5: Place a glove or a plastic bag over all water spouts to ensure water does not drip onto the surface while undergoing resurfacing. Using a blow dryer or strong wet-vacuum, blow water out of drain and wall areas. When the surfaces are completely dry, use blue painters tape to mask off walls around the bathtub and tub drain.

NOTE: *Drying surfaces completely, especially at the drain, is critical to the success of the refinishing coating. ANY moisture while resurfacing will result in product and bonding failure.*

NOTE: Any repairs, if needed, should be made before using a tack cloth.

STEP 6: Using a tack cloth, rub over the entire surface in effort to remove all foreign materials from the areas. The bathtub or wall surfaces should now be smooth, completely cleared, and ready to be rolled with the refinishing product.

CAUTION: In the following steps - proper ventilation, gloves, and eye wear are strongly recommended. Use all paint products with caution. For best results, use when can is between 50° F and 90°F (10° C and 32° C.) **PROTECT AND COVER NEARBY SURFACES** - aerosolized paint has the potential to travel and coat nearby surfaces, please use product with care.

STEP 8: Shake can for at least one minute after rattle is heard and occasionally during use.

STEP 9: Remove cap from the **Aerosolized Paint Can**. Attach the provided **Comfort Hand Grip** to one of the spray cans by first tilting the front of the grip downward into the ridge on the top of the can so the spray nozzle is inside the space on the grip. You may need to use another hand to add stability and rotate the grip around the can to find a spot on the ridge where the grip will take. Next, use some downward and forward force on the hand holding the grip to get the other side of the holder to snap into place on the ridge of the can. Ensure the spray nozzle is facing outwards in line with the hand grip by rotating either the nozzle or the grip. Once the grip is locked into place, the spray can is ready to be used.

STEP 10: Spray surface with even and steady strokes at a distance of 8 to 10in (20 to 25cm.)

NOTE: If clogging develops, turn spray nozzle 1/4 turn or remove and clean spray nozzle slot. **DO NOT** stick pin or any other object into can opening. With can spray nozzle pointed away from you, reinsert spray nozzle with a gentle, twisting motion. To clear spray nozzle for future use, turn can upside down and spray for three seconds.

NOTE: Surfaces will be dry to the touch in about one hour. The paint will take 24 hours to fully cure. **DO NOT** use surfaces before being fully cured.

OPTIONAL: A second coat may be applied right away following the same pattern. Ensure that you do not lean on wet surfaces.

NOTE: Dispose of all unused materials and debris immediately after completing the project. Obey all state, city, & town codes for proper paint disposal. See "**Safety**" section at the end of these instructions for more details.

STEP 11: After allowing coating to set for **45 minutes**, carefully remove the tape by pulling at a 45 degree angle. Please allow refinished surfaces to dry **24 hours** before use. If caulk was removed before resurfacing, reapply using 100% Silicone caulk once surfaces are dry. Allow caulk to dry, and rinse refinished surfaces with warm water before use.

Thank You for Choosing

The logo for Bathworks Refinishing Products. The word "Bathworks" is in white, with the "o" in "works" highlighted in green. Below it, "REFINISHING PRODUCTS" is written in white capital letters. The entire logo is set against a dark blue rectangular background.

Bathworks®
REFINISHING PRODUCTS

Please enjoy 10%* off your next total purchase made on our website:

bath-works.net

Using coupon code:

A dark blue ribbon banner with the text "DIY10" in white, bold, sans-serif capital letters.

DIY10

*Standard exclusions apply. 10% off total Bathworks® order. Offer valid only at <https://www.bath-works.net>. May not be used in conjunction with any other coupon. Employees not eligible for discount. This offer may be modified by Tub Refinishing Inc, DBA Munro Products, in its sole discretion without notice at any time.

BATHTUB CARE TIPS

Congratulations!

Your bathtub or bath fixture has just been resurfaced with the finest product in the tub and tile coating industry. Follow these care tips to maintain the beauty of your surface.

- Treat as if this is a brand new bathtub; remove excess water and wipe dry after each use.
- Always be certain faucets are tightly closed and the shower pipe is drained after each use.
- DO NOT rest any soap bottles, spray cans, or wet clothes on the surface for extended periods of time.
- NEVER use hair dye in a refinished bathtub.
- If bathing pets in the bathtub, always place a towel down to prevent scratches.

Bathmats

If you do not have the non-slip system applied to your surface and you find it to be too slippery, you may use a NON-SUCTIONED bathmat or a towel (these must be picked up after each use.) Do not hang the mat or towel over the bathtub.

Use of a suctioned bathmat or stick-on strips will cause failures of the resurface coating.

Cleaning

Even though the bathtub does not look dirty, it should be cleaned at least once a week with a liquid NON-ABRASIVE cleaner (Scrubbing Bubbles®, 409®, or Fantastic® are recommended products.) NEVER use bleach or abrasive cleaners (Ajax®, Comet®, or Soft Scrub®) on a refinished surface. If the non-slip protection system is applied to the bottom of your bathtub, you may use Soft Scrub® on that area if needed.

Remember

If you treat your new surface with respect, clean it regularly, and keep your taps dry - your tub will stay beautiful and radiant for years to come! Use Bathworks® Cleaner and Polishing Kit for the ultimate shine and protection!

LIMITED WARRANTY

Tub Refinishing, Inc. DBA Munro Products as follows; this warranty is in lieu of all other written or unwritten, expressed, or implied warranties, and Tub Refinishing, Inc. DBA Munro Products expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals, or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals, and can also be flammable.

SAFETY

A protective respirator should be worn if available. Use product with adequate ventilation. Always use rubber gloves. Tub Refinishing, Inc. DBA Munro Products is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. Keep all refinishing kit materials and tools away from children, animals, and individuals sensitive to paint or fumes. Some items in this kit are flammable and should be disposed of properly in accordance to local state, city, & town codes regulating used paint products. Use all paint products with caution. **DO NOT** dispose of paint or clean tools by using water and flushing down household drains - these are solvent-borne products and may potentially damage pipes & the environment. Use **Xylene** or comparable cleaner for cleaning tools & spills. Xylene is capable of permanently damaging surfaces such as linoleum, plastic, wood, and previously painted surfaces. Never use xylene on skin and use gloves & eyewear while using. If you are unsure about the use or safety of this product, please return the unopened and unused kits to the supplier. All returned goods are at the purchaser's cost. Opened or used materials will be refused for credit.

See all **Safety Data Sheets** (SDS) which are available via our website: **bath-works.net**

SUITABILITY FOR USE

The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, disposal, use, and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitability of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use caution.

FOR EMERGENCY: CHEMTREC® 1-800-424-9300

The logo for Munro Products, featuring the word "munro" in a bold, lowercase, sans-serif font, with "PRODUCTS" in a smaller, uppercase, sans-serif font directly below it. The text is white and is set against a dark blue rectangular background.

**America's #1 Choice in Bathroom Restoration
For Over 50 Years!**

"Like" us on [facebook.com/munroproducts](https://www.facebook.com/munroproducts)

*Tub Refinishing, Inc. DBA Munro Products, and Bathworks®.
Bathworks® is an exclusive trademark of this company.*

www.bath-works.net