

"CLEAR DRAIN" INSTALLATION INSTRUCTIONS

Standard Installation

1. Hold the "Clear Drain" unit with label facing outwards up to the air conditioner drain line as close as reasonably possible to the air handler.
2. Mark the 3/4" PVC drain line coming out of the air handler where the ribs on the "Clear Drain" unit are located (2 places)
3. Cut the 3/4" PVC drain line at the 2 marks.
4. Glue each end of the drain line pipe into the sides of the "Clear Drain" unit with approved PVC glue and position in an upright manner.
5. Let the PVC glue dry as needed per the glue instructions.
6. Insert the Gel Tab cartridge into the "Clear Drain" unit and replace the top cap.



Customized Installation

1. Hold the "Clear Drain" unit with label facing outwards up to the air conditioner drain line as close as reasonably possible to the air handler.
 - a. If the "Clear Drain" unit cannot be installed at this location due to the air handler base frame obstructing the "Clear Drain" unit, then the 3/4" PVC drain line pipe will need to be re-routed so that the "Clear Drain" unit is not obstructed by the air handler base frame.
2. Cut the 3/4" PVC drain line pipe and install PVC parts, as needed, in order to locate the "Clear Drain" unit so that it clears the air handler base frame.
 - a. The use of 45 degree angles is preferred rather than 90 degree angles, if possible.
3. Glue each end of the drain line pipe into the sides of the "Clear Drain" unit with approved PVC glue and position in an upright manner.
4. Let the PVC glue dry as needed per the glue instructions.
5. Insert the Gel Tab cartridge into the "Clear Drain" unit and replace the top cap.



To view the chemical safety data sheet please visit our website at www.cleardrainac.com