

## AN ORIGINAL GRANITE BRACKET. PRODUCT

## THE DOUBLE SIDED ISLAND SUPPORT BRACKET

Designed to give support to a counter top that has an overhand on both sides of the cabinet.



1. Mark 3"-6" from the outer edge of the cabinet for your first pocket to be cut. Then set marks for the remaining brackets every 16"-20" apart for the best counter top protection. Do this on both sides of the cabinet.



**4.** Using a level, make sure your brackets are level; use shims where necessary until the brackets are completely level.



**2.** Rout or chisel a 2.5" wide by 0.5" deep pocket at each mark on both sides of the cabinet. This "pocket" will allow the bracket to sit flush with the top of the cabinet. (Make sure it is flush)



**5.** Place your counter top on top of the cabinet and brackets.



**3.** Once the "pocket" is made in the cabinet, simply insert the bracket.



**6.** Check once again that the counter top is level. Once level, caulk around the brackets with clear silicone to hold your counter top securely.

