



# AN ORIGINAL GRANITE BRACKET™ PRODUCT

## THE ORIGINAL™ HIDDEN ISLAND BRACKET



1. Mark 2"-4" from the outer edge of your cabinet for your first notch to be cut. Then set marks for the remaining brackets every 16"-20" apart. Rout or chisel out a 0.5" deep by 2.5" wide notch from the cabinet. Top of bracket should be flush with top of the cabinet.



2. Once your kitchen island cabinet is notched, place your brackets in the notch. Slide your brackets into place against the top stretcher. Ensure the top of the bracket is flush and level with the top of the cabinet.



3. Once your brackets are in place and level, using the holes on the bracket as a guide, drill pilot holes into the top stretcher. Once pilot holes are made, drill the screws through the pilot holes, fastening the bracket to the stretcher.



4. Now that your brackets are properly secured and in place, place the countertop of your choosing on top of the brackets.



5. With your countertop now resting upon your brackets, we recommend applying a bead of clear silicone adhesive around the brackets.



SCAN FOR  
MORE PRODUCTS

**ORIGINALGRANITEBRACKET.COM | 888-584-1112**

\*AVAILABLE  
IN MULTIPLE SIZES