

INSTRUCTIONS

Remove protective clear caps. Cut rod to size if needed. Slip metal end caps over ends of shower rod, then put the clear caps back on. Check height and level of rod. Mark hole positions. Drill pilot holes (1/8-in for wood studs and 3/16-in for drywall and anchors). Use proper drill bit if installing to wall tile with anchors (carbide tip for ceramic, diamond tip for hard porcelain and natural stone). Secure end caps with screws.

INSTRUCCIONES

Retire las tapas protectoras transparentes. Corte la varilla a la medida, de ser necesario. Coloque las tapas metálicas para los extremos sobre los extremos del cortinero para ducha y, a continuación, vuelva a poner las tapas transparentes. Verifique la altura y la nivelación de la varilla. Marque la posición de los agujeros. Taladre agujeros guía (3.17 mm para montantes de madera y 0.47 cm para paneles de yeso y anclas de expansión). Utilice la broca para taladro adecuada si va a instalar en baldosas para pared con anclas de expansión (punta de carburo para cerámica, punta de diamante para porcelana dura y piedra natural). Proteja las tapas para los extremos con tornillos.