

## Installation Instruction

Better Vanity IIIStallation IIIStruction							
PARTS LIST							
NO.	PARTS	NAME	QTY	NO.	PARTS	NAME	QTY
1		Hangs board	1	5		Cabinet body	1
2	1	M4x60 Countersunk head screw	2	6		M6x65 Screw	2
<ul><li>3</li><li>4</li></ul>	1	25 x 25 x 430 Aluminum bar with holes M4 x 14 Flat head tapping screws	7	7		Basin	1
		6			Install hang	Installation Step Please make sure to in screws on the solid pa	stall
	Hang up	the cabinet	2		Fix the cab	B 1:3	③
	Ins	stall the basin	4		Finis	shed	(£)