

Align screen door pull position, drill pilot holes,
then secure with 2 screws included.

