



ARMOUR SCREEN

DO-IT-YOURSELF
Gutter Protection



EASILY LOCKS INTO PLACE

Protect your home's foundation, shrubbery and roots while controlling erosion.

Easy Install: 2 Simple Steps | Perfect for the DIYer

Fits Standard 5" Gutter: Includes: 5 Panels at 5" x 36"

2 EASY INSTALLATION STEPS

1



Clean gutter and place the Armour Screen on the gutter with the flat edge towards the house.

2



Push the front edge of the Armour Screen towards the front lip of the gutter, the C-Lock Clip will snap into place. The back edge of the screen should be pushed down and even with the back of the gutter. Some upward bowing in the middle of the screen is normal. If the screen is bowing downward, please remove the screen and try placing it again. Continue installing the screens until you reach the end of the gutter. Cut the last piece to size and fasten as described.



Easy to Snap: C-Lock Clip
The C-Lock Clip design ensures that the Armour Screen snaps into place on the front edge of your gutters.

PREVENTS
Clogs From:



Sweet Gum



Dogwood



Oak



Maple

spectraproselect.com

SPSASCREEN