

Spring Clip Hardware Installation Instructions

What You Need

Tension Spring Clips
3/16" Bolts
3/16" Cap Nuts



Installation

1. Place the window well cover over the window well and push it tight against the exterior of the house. (FIGURE A)
2. Center the cover on your well and mark the locations where the clips will attach. (FIGURE B)
3. Remove the cover from your well and drill a 3/16" hole at each marked location. (FIGURE C)
4. Mount the clips to your cover using the provided cap nuts and bolts provided and tighten the screw until you've reached your desired tension. (FIGURE D)
5. Snap the window well cover onto the rim of the window well. (FIGURE E)

Cleaning Instructions

Clean your window well cover with a mild solution detergent and water. Use of harsh chemicals or solvents may damage plastic and void warranty.

FIGURE A




FIGURE B




FIGURE C



FIGURE D





FIGURE E



For warranty information, visit our website