

Align gate pull position, drill pilot holes,
then secure with 4 screws included.

