

CAUTION: Do not turn handle before or while installing the saddle tapping valve. Be sure the piercing lance does not protrude beyond the rubber gasket.

Installation Instructions:

1. Install the saddle tapping valve on the cold water copper tubing so that the outline is positioned in a convenient direction.
2. Tighten screw evenly. Brackets should be parallel. Tighten firmly, but do not overtighten.
3. Connect copper tubing to saddle valve outlet.
(fig. 1)
4. Coil a minimum of 8 ft. tubing (3 turns - 10 in. dia.) behind refrigerator. This will allow refrigerator to be moved away from wall for cleaning or service.
5. Cut tubing length required to make connection at refrigerator.
(fig. 2)
6. If refrigerator connection has male plastic fitting, use adapter included to make connection.
7. Turn the saddle tapping handle clockwise until you feel it is firmly seated. Note: You have now pierced the copper tube and the valve is closed.
8. Turn the handle counterclockwise to open the valve.
9. Check for leaks.

