

## U-CLAMP ASSEMBLY INSTRUCTIONS

1. Hook the closed end of the U-Clamp over the receiver flange.
2. Slide Cross Bar over the U-Clamp Threads and position Cross Bar on Ball Mount in front of the receiver box.

