



# INSTALLATION INSTRUCTIONS FOR INTERIOR PREHUNG DOORS

## TOOL REQUIRED:

- Hammer
- 4 Feet Level
- 2-inch finish nails
- Wood or plastic shims
- Hand Saw
- Construction knife
- Measurement Tape
- Pencil

## BEFORE YOU START INSTALLATION CHECK YOUR ROUGH OPENING(80 INCH HIGH)

Door Size	Overall Dimensions	Overall Dimensions	Rough Opening (R.O.)	Rough Opening (R.O.)
	<i>Width</i>	<i>High</i>	<i>Width</i>	<i>High</i>
18"	19 1/2"	82"	20"	82 1/2"
22"	23 1/2"	82"	24"	82 1/2"
24"	25 1/2"	82"	26"	82 1/2"
28"	29 1/2"	82"	30"	82 1/2"
30"	31 1/2"	82"	32"	82 1/2"
32"	33 1/2"	82"	34"	82 1/2"
36"	37 1/2"	82"	38"	82 1/2"
36" (Double Door)	37 3/4"	82"	38 1/4"	82 1/2"
44" (Double Door)	45 3/4"	82"	46 1/4"	82 1/2"
48" (Double Door)	49 3/4"	82"	50 1/4"	82 1/2"
56" (Double Door)	57 3/4"	82"	58 1/4"	82 1/2"
60" (Double Door)	61 3/4"	82"	62 1/4"	82 1/2"
64" (Double Door)	65 3/4"	82"	66 1/4"	82 1/2"
72" (Double Door)	73 3/4"	82"	74 1/4"	82 1/2"

**BEFORE YOU START INSTALLATION CHECK YOUR ROUGH OPENING(96 INCH HIGH)**

Door Size	Overall Dimensions		Rough Opening (R.O.)	
	Width	High	Width	High
18"	19 1/2"	82"	20"	98 1/2"
22"	23 1/2"	82"	24"	98 1/2"
24"	25 1/2"	82"	26"	98 1/2"
28"	29 1/2"	82"	30"	98 1/2"
30"	31 1/2"	82"	32"	98 1/2"
32"	33 1/2"	82"	34"	98 1/2"
36"	37 1/2"	82"	38"	98 1/2"
36" (Double Door)	37 3/4"	82"	38 1/4"	98 1/2"
44" (Double Door)	45 3/4"	82"	46 1/4"	98 1/2"
48" (Double Door)	49 3/4"	82"	50 1/4"	98 1/2"
56" (Double Door)	57 3/4"	82"	58 1/4"	98 1/2"
60" (Double Door)	61 3/4"	82"	62 1/4"	98 1/2"
64" (Double Door)	65 3/4"	82"	66 1/4"	98 1/2"
72" (Double Door)	73 3/4"	82"	74 1/4"	98 1/2"

**PRE-HUNG DOOR INSTALLATION IN A FEW EASY STEPS (SINGLE DOOR)**

**Step 1: Prepare the Door**

- Remove the plastic shipping pin that secures the door in place.

**Step 2: Check Door Opening Alignment**

- Use a level to ensure the door opening is plumb (vertically straight) and square.

**Step 3: Verify Door Handing**

- **Right-Hand Door:** When the door swings toward you, hinges are on the left, and the knob hole is on the right.
- **Left-Hand Door:** When the door swings toward you, hinges are on the right, and the knob hole is on the left.



#### **Step 4: Position the Door**

- Lift the door into the opening, bottom first, handling it from the hinged side.
- Check with a level to ensure the hinge-side jamb is perfectly vertical.

#### **Step 5: Shim and Align**

- Insert shims between the jamb and framing on the hinge side and top.
- Adjust shims as needed until the door is level and plumb.

#### **Step 6: Secure the Jamb**

- Once aligned, drive two nails through the jamb at each shim location to secure it in place.

#### **Step 7: Finishing Touches**

- Countersink all nails for a clean finish.
- Paint the door and jamb if desired (no sanding required—factory-primed).
- Install the door knob according to the manufacturer's instructions.

#### **Step 8: Test Operation**

- Open and close the door to ensure smooth operation. Enjoy your new solid-core interior door!

### **PRE-HUNG DOOR INSTALLATION IN A FEW EASY STEPS (DOUBLE DOOR, FRENCH DOOR)**

**NOTE: THE DOUBLE DOOR (FRENCH DOOR) COMES PRE-HUNG BUT DISASSEMBLED BECAUSE OF THE DOOR'S WEIGHT AND DIMENSIONS AND FOR A BETTER INSTALLATION EXPERIENCE. DOOR SLABS DON'T HAVE PREDRILLED HOLES FOR THE KNOB. TOO MANY VARIATIONS ON HOW THIS DOOR CAN BE USED PREVENT BAD EXPERIENCES, CUSTOMERS DECIDING HOW TO INSTALL KNOBS ON THE SIDE.**

#### **Step 1: Prepare Hardware**



- Locate the screw bag attached to the door jamb.

### **Step 2: Assemble the Door Jamb**

- Connect the jamb sides using the provided 1" black Phillips screws.
- Ensure hinges on both jambs are aligned on the same side.
- The top stopper on the jamb should align seamlessly without offset.

### **Step 3: Remove Hinge Screws Temporarily**

- Unscrew the hinges from the jamb for easier installation.

### **Step 4: Check Opening Alignment**

- Use a level to confirm the rough opening is plumb and square.

### **Step 5: Install the Jamb**

- Position the assembled jamb into the opening.
- Secure with nails through the hinge-routed areas, using shims as needed for alignment.

### **Step 6: Attach Door Slabs**

- Reattach the door slabs to the hinges on the installed jamb.

### **Step 7: Adjust for Smooth Operation**

- Fine-tune shims and hinges until the doors close evenly without binding.

### **Step 8: Install Catch Ball Plates**

- Affix the provided catch ball plates at the top of the jamb using included screws.

### **Step 9: Final Finishing**

- Paint if desired (no sanding required—factory-primed).
- Install door knobs per your preferred configuration.

### **Step 10: Test and Enjoy**

- Ensure both doors open and close smoothly. Your new French doors are now ready for use!

