Standard Mounting Instructions



pewag USA Traction Chains



Mounting Instructions



Lay the chains out on the ground with the cross chain hooks facing up, make sure there are no twists in the chain. Grab the middle of the chain and lay them evenly on top of the tire with the cams on the outside of the tire. Cross chain hooks should be facing away from the tire (see picture). Tuck the end of the chains in the rear of the tire and rollback about 2 feet if space allows.






Start by hooking the speed hook on the inside of the tire, and then fasten the hook on the outside of the tire. Try and have them even or close to the same link on the inside as the outside, so one side chain isn't pulling more than the other. Try to get the inside and outside side chain as tight as possible.









If you are in a safe situation, drive 150-300 feet and let the chain center on the tire. Check for tightness and make sure the chain is centered like the picture shows. Often times you can close the last cam at this point to get a good fit, or you might need to undo the cams and get one more link tighter on the outside speed hook. Then re-tighten cams for proper fitment. Multi-arm adjuster recommended.

pewag Traction Chain, Inc.

190 Greenhorn Drive, Pueblo, CO 81004 Toll Free: 800-445-2895, Fax: 719-691-1847 traction@pewagchain.com pewagchain.com

D

youtube.com/pewagUSA



facebook.com/pewagtraction



instagram.com/pewagtraction



Model specific install instructions available on our website



