

Align sash lift position,  
drill pilot holes, then secure  
with 2 screws included.

