


SecurePro Security Screen INSTALLATION GUIDE

©2014 202220845 2.14



1. Slide the expander onto the bottom of the window unit (Figure 1). (The emergency release feature is located on the lower sash).
2. Position the screen over the opening to check for a proper fit.
3. Predrill using a 1/8" drill bit, and temporarily secure the top corners of the screen with two Phillips head installation screws (Figure 2).
4. Adjust the expander so that it makes even contact across the bottom of the existing window sill.
5. Predrill and install the remaining Phillips head installation screws.
6. Ensure that the screen panel has clearance to swing out freely by operating the emergency release feature.
7. Remove one Phillips head screw from each corner and replace with one-way slotted security screws, using a flathead screwdriver (Figure 3).
8. To improve weather protection, caulk the head and jamb mounting flanges. To allow for proper drainage, do NOT caulk the sill (Figure 4).

