

surface wrap

Quick Installation Guide

Before you Start

For better results, remove all hardware, hinges, and screws from the cabinet door before applying Surface Wrap films.

Tools you will need



- Isopropyl Alcohol
- LX PM04 Primer
- Applicator Swab
- Squeegee
- Hobby Knife
- Sandpaper
- Scissors
- Rag



1 Clean front, and all sides of cabinet door using isopropyl alcohol. Ensure the surface is clean of any oil or residues before starting



2 Apply LX water-based primer PM04 to all four sides and a one-inch strip along the top edge of the cabinet door using an applicator.



3 Expose 5-7 inches of the adhesive, cutting away the excess backing. Lay the film adhesive-side up. Center the cabinet door on the film and press it onto the adhesive.



4 Flip the door and use a squeegee to press the film down firmly. Sweep from one side to the other. With one hand, pull back the remaining protective paper while sweeping the squeegee evenly with the other.



5 Cut a 45-degree slit at each corner of the film. Fold and press the film tightly over the door edges and corners. Burnish the wrapped corners with your fingers. Fold and overlap flaps on opposite sides. Use a blade to trim excess film.



6 Using a sanding block with fine-grit sandpaper, sand all four edges smooth with an angled sweeping motion toward the center of the back of the cabinet door. Once smooth, wipe away the sanding dust. **You're done!**

Optional Steps

If finishing the back side of the door is necessary or desired, repeat STEP 3 and 4 on the back. Trim the excess film to the back edge of all four sides. Use the sanding block to smooth the edges for a uniform finish.

