

PLUGGING WATER LEAKS using Leak Stopper Project how-to guide

The Pro's Choice Since 1936

PREPARATION



MIX ACCORDING TO DIRECTIONS ON THE PAIL.

NOTE: This is a fast-setting product. Mix only small amounts.



APPLICATION



Using gloved hands, work the product back and forth between hands until the product begins to stiffen.



Once the product has begun to stiffen, force a large amount of product into the hole. Overfill the hole and the surrounding area.



FINISHING



Allow the product to harden for 1-2 minutes. Scrape off the excess using a trowel.



Using a wet rag, remove any excess material so the patch is flush with the surface.

NOTE: For complete product information, please refer to the product data sheet.