

Surfaces[®] by NRS[®]

Kitchen Cabinet Components



Tools & Materials needed to install end panels:

- Tape measure
- 150 grit sandpaper or sanding block
- Utility knife
- Table or Circular Saw
- Router (if available)
- J-Roller/Wood scraper
- Tack cloth
- Mini-Vac
- Hammer
- putty knife
- 3' straight edge
- Contact cement or adhesive
- Wood glue
- Finishing nails (optional)

Tips for Installing End Panels:

Surface Prep: Make sure the end panel and cabinet surfaces are free of dust/dirt before applying.

Cutting: Use a router to cut the end panel to fit the cabinet height/width; then hand file or use 150 grit sand paper to make a smooth edge. If the countertop is already installed then you'll need to cut the end panel to the correct size using a table or circular saw. Use a straight edge and scoring the panel with a utility knife before cutting. Otherwise, install the entire end panel and cut it to fit once installed.

Adhering: Use contact cement on both the end panel and the surface you're applying the end panel to. If you're using construction adhesive or wood glue allow for proper curing time (see manufacturer's recommendation) before cutting or trimming the end panels.

Finishing: Make sure the panel is flush the cabinet front and bottom. Apply pressure using a 4-5" J- Roller/Wood Scraper. (Note: Start in the middle of the panel and apply pressure in the direction of the grain.)