

### Perfect Finish® **FibaTape®** SELF-ADHESIVE DRYWALL TAPE



**TIME REQUIRED:** 10 minutes + dry time



**SKILL LEVEL:** Easy - DIY friendly

#### REPAIRING CRACKS


These instructions are for surface repairs. Damage caused by structural or framing defects should be addressed by a professional.

#### TOOLS & MATERIALS

- Perfect Finish drywall joint tape
- Taping knife
- Joint compound or spackle
- Sanding block



Self-Adhesive



Ultra-thin



Easy to conceal

1. Clean the surface of the damaged area, removing all dust and debris.
2. Apply a strip of mesh tape directly over the crack.
3. Apply spackle or joint compound over the tape, feather a few inches past the tape edges on all sides.
4. Allow compound to dry according to manufacture's instructions.
5. Sand area with a fine grit sanding block until smooth.
6. Apply a second coat of compound, feathering the edges out a little farther than the first coat. Sand to a smooth finish. Repeat steps 5 & 6 as needed.

