

INSTALLATION SHEET **QKK** Lock Sets

С

F



Step 5 Connect wire loom from

Front Assembly to Back Module.



backset (from edge of door to center of door lock)

Step 6

Fasten Back Module to the Back Mounting Plate. DO NOT OVER TIGHTEN. Install premium alkaline batteries.



A

В

Е

Step 3 Mount Front Assembly on door, routing wire loom UNDER latch and assuring Square Tube is face up.



Step 7 Fasten Battery Cover to Back Module.



Step 4

Install Back Mounting Plate (arrow showing) & route wire loom through rectangular hole.



Morning Industry thanks you for your business and invites you to check out the new and exciting products on our web site: http://www.morningindustry.com.