

Align brace position, drill pilot holes, then secure with 5 screws included.

