

Align brace position, drill pilot holes, then secure with 6 screws included.

