



DEVELOPED BY
ANCHOR
DIAMOND
WALL INDUSTRY EXPERTS



HOW TO INSTALL EDGERS

- Step 1:** Lay out the project by using stakes with a string line or garden hose. Dig a trench 6" wide and 4" deep.
- Step 2:** Firmly compact the soil in the bottom of the trench with a tamper. Place 1 inch of paver base in the bottom of the trench and firmly compact.
- Step 3:** Position edge units end to end in the trench. Using a rubber mallet, tamp the edgers firmly into place. Use a carpenter's level to ensure edger units are uniformly level. Continue to place the units until the desired length of the project is finished.
- Step 4:** If necessary, edger units may be cut using a circular saw with a masonry blade or split with a hammer and chisel. Read and understand the operating manual before using a saw. Finish project by firmly packing soil along sides of edger units and replace sod or mulch.



CHISEL EDGE™


EDGER

OLD WORLD CHARM EDGING
FOR WALKWAYS, PATIOS AND
GARDEN BEDS

✓ FEATURES & BENEFITS

- Uniquely shaped for installation ease in both straight and curved applications
- 3 face patterns
- A distinctive, sculpted face style that provides superior aesthetics
- Created to keep soil and mulch in place while providing a root barrier to unwanted garden grass and weeds
- The perfect addition to the ChiselWall® wall system, allowing homeowners to install a simple yet beautiful and harmonious look in their yard
- Minimum diameter 60"
- Minimum curve radius 30"

🧱 SHAPES & SIZES

EDGER UNIT	Approx Dims (in)	Approx Weight (lbs)	Coverage (sqft)
	3.5 x 10.5 x 3.43	7.8	.85



ANCHOR
DIAMOND

ANCHOR DIAMOND Group
5909 Baker Rd. Suite 550
Minnetonka, MN 55345
📞 1-952-933-8855

For more info visit
AnchorDiamond.com



©2023 ANCHOR DIAMOND Group. All rights reserved.
AD23-001-CHISEL EDGE