

Tools Needed:

Implementos
necesarios:






For warranty info visit
mdbuildingproducts.com

Para obtener información sobre la
garantía, visite mdbuildingproducts.com

SQUARE PULL

1. Cut notch in door 1-3/4" deep and 2-3/16" high.
2. Place square pull in position making sure fork arms engage pin on each side.
3. Tighten screws equally until square pull is entered in notch. Drill a 3/32" pilot hole to the length of the short screws and tighten the screws.



TIRADOR CUADRADO

1. Corte una muesca en la puerta de 1-3/4" de profundidad y 2-3/16" de altura.
2. Coloque el tirador cuadrado en posición asegurándose de que los brazos de la horquilla enganchen el pasador en cada lado.
3. Apriete los tornillos por igual hasta que el tirador cuadrado entre en la muesca. Taladre un agujero piloto de 3/32" a la longitud de los tornillos cortos y apriete los tornillos.

Made in China. Hecho en China.
M-D Building Products, Inc.
Oklahoma City, OK 73118
Rev 07/24 mdteam.com

⚠WARNING: Cancer and Reproductive Harm
- www.P65Warnings.ca.gov.

ADVERTENCIA: Cáncer y Daño
Reproductivo - www.P65Warnings.ca.gov.



QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

