

PERGO Gold[®]

Premium Underlayment

INSTRUCTIONS:

- 1) Be sure the floor is clean and dry before installing underlayment. Pretest substrate for moisture emissions prior to installation of underlayment. Ensure that the underlayment seams will run perpendicular to the flooring seams.
- 2) Starting in a corner, install the first row of underlayment with the non “lip and tape” side up against the wall and the overlapping “lip and tape” side towards the open side of the room. The gold moisture barrier must be facing upward. Install the underlayment to the far wall and cut around any obstacles using a utility knife.
- 3) Align the second row of underlayment to the first row.
- 4) Flip the first row’s overlapping lip onto the second row and secure it using the adhesive tape strip located on the overlapping lip. To activate the adhesive, remove the liner and apply hand pressure to seal the seams.
- 5) Repeat this process until the entire floor is covered and sealed. Ensure that all foam seams without the overlapping lip tape are sealed with underlayment seam tape (sold separately). It is not necessary to tape the outer perimeter of the room’s underlayment. After underlayment installation is complete, install your flooring according to the manufacturer’s instructions.

SPECIFICATIONS:

Dimensions:

3 mm thick x 4 ft wide x 25 ft long

Moisture Protection:

0.01 pounds/24 h/1,000 sq ft

Impact Sound Insulation:

IIC 71/STC 66/Delta 21

(on a 6” slab with drop ceiling)

IIC 75/STC 66/Delta 21

(on a 8” slab with drop ceiling)

Thermal Insulation:

R-Value 0.59

Smoothing:

2.5 mm

Compression Strength:

> 15 PSI

Safety:

Odorless, non-toxic,
100% recyclable



www.pergo.com | 1-800-33-PERGO



Easy to install!

Ensure that all foam seams without the overlapping lip tape are sealed with underlayment seam tape. (Sold separately)