

DIG-FREE® EDGING KIT

INSTALLATION GUIDE



1. Water the Installation Area

Water the area to soften the soil. Wait for the water to soak in, then begin installation while the soil is still moist.

Note: Clay/hard soil may require more water. If edging is difficult to insert, add more water to soften the soil.



2. Install the Edging

Start at one end. Place stakes on the grass side, rock the piece side to side to ease it into the soil, then give a final push using your body weight.

Repeat with remaining pieces.




3. Finish

Add flowers, mulch, rock, or other landscaping materials to complete your project.

HELPFUL TIPS:

CLAY/HARD SOIL: May require more water to soften soil.

ROCKY SOIL: Clear large rocks before installing.



Holes in built-in stakes are for future root growth, not stakes.

View the Installation Video



Dig-Free® is a registered trademark of Avon Plastics Inc. Copyright © 2026 Avon Plastics Inc. All Rights Reserved.

MADE IN USA
FROM RECYCLED MATERIALS

Questions/Comments?
CustomerService@AvonPlastics.com


AVON PLASTICS