

EASTMAN®



INSTALLATION AFTER PLACEMENT OF COUNTER TOP



STEP 1:

For new or remodel installations where the counter top has already been placed, bend the end tabs of the dishwasher bracket into a 90 degree angle as shown, with the raised panels facing up.



STEP 2:

Apply silicone or rubberized adhesive caulk to the three raised panels on the bracket as shown. This provides shock absorption to withstand the daily use of the dishwasher door.



STEP 3:

Put the bracket into place under the counter top with the tabs flush to the cabinet facing. Press bracket up against the counter top – the bracket design will conceal any caulk squeeze out.



STEP 4:

Attach bracket to the cabinet sides with (4) #6X1/2" wood screws (provided). Caulk edges to provide a finished seal.



STEP 5:

Attach the dishwasher straps to the dishwasher bracket using one of the many attachment holes. This will result in a secure and professional finished installation.

EASTMAN®



INSTALLATION BEFORE PLACEMENT OF COUNTER TOP



STEP 1:

Place the dishwasher bracket across the dishwasher opening on top of the cabinets with the raised panels facing up and the tabs flush to the cabinet facing. Secure the bracket with (4) #6X1/2" wood screws (provided).

These are the same size screws used to anchor hinges to delicate cabinet doors.



STEP 2:

Apply silicone or rubberized adhesive caulk to the three raised panels on the bracket as shown – the bracket design will conceal any caulk squeeze out. This provides shock absorption to withstand the daily use of the dishwasher door.



STEP 3:

The counter top can now be installed on top of the bracket. To install the dishwasher, attach the dishwasher straps to the dishwasher bracket using one of the many attachment holes. This will result in a secure and professional finished installation.

