

Align hinge position,
drill pilot holes,
then secure with
6 screws included.

