



AN ORIGINAL GRANITE BRACKET™ PRODUCT

THE ORIGINAL™ INDUSTRIAL LARGE SHELF BRACKET



1. Locate wall studs with a stud finder and mark locations; Install blocking or additional studs if necessary for your project.



2. Select desired height for your bracket and ensure they are level.



3. Once your brackets are in place and level, using the holes on the bracket as a guide, drill pilot holes into your wall studs. With your pilot holes now made, fasten your brackets to the wall by screwing them into your wall studs.



4. Now that your brackets are properly secured and in place, place the countertop of your choice on top of your brackets.



5. With your countertop now resting upon your brackets, we recommend applying a bead of clear silicone adhesive around the brackets.



SCAN FOR
MORE PRODUCTS

ORIGINALGRANITEBRACKET.COM | 888-584-1112

*AVAILABLE
IN MULTIPLE SIZES