

Strait-Flex® Perfect 90° **Premium Trims and Tapes**

Installation:

1. Fold Perfect 90° in half at center crease with print size facing each other. For intersecting corners, cut ends at 45° angles. For inside corners, fold less than desired angle with print side facing out.
2. With a 5" or 6" taping knife, apply a smooth, liberal coat of compound to corner.
3. Press Perfect 90° into the wet compound. Adjust if necessary to create a straight line.
4. Wipe down tight with taping knife using a little additional pressure on the outer edges of Perfect 90°. Let dry completely several hours or overnight.
5. Apply final coat to perforated edge only. No compound is needed over finished area of tape. It's ready to paint. Let dry completely over several hours or overnight.
6. Sand lightly with 120 grit sandpaper. Perfect 90° will not fuzz-up like paper or mesh tapes.

