

Shower Bar Installation



Step 1: Remove chrome cover cap from each of the two chrome posts and carefully loosen dual set screws

Step 2: Slide the adjustable holder onto middle of the bar by squeezing the button. Slide ends pieces onto bar and lightly tighten dual set screws

Step 3: Position in shower to optimum height and adjust chrome post to desired position. Tighten dual set screws until firm (do not over tighten)

Step 4: Clean surface with alcohol pad and let dry completely. Attach adapter to each end post and peel and set in position. Unscrew adapter and remove bar.

Step 5: Pierce adhesive tube with red key and inject into one hole until it beads up the opposite check hole. Let stand undisturbed for 12 hours.

Step 6: Assemble bar to adapter and attach the hand shower

