

INSTALLATION

1. In order to properly install Artis Wall™ you will need the following tools: 1) a utility knife, 2) a tape measure, 3) a straight edge, 4) scissors, and 5) a pencil.
2. Place the open Artis Wall boxes in the room to be installed for a minimum of 7 days prior to installing. This allows the planks to adjust to the relative humidity in the room.
3. Before beginning the installation process, you will want to make sure your walls are clean and free from debris. After washing with clean water and drying the wall, measure to determine the height of your wall.
4. Measure and cut A.I.M.™ strips to the exact height of your wall. You will need 1 A.I.M.™ strip for every 10 inches to cover the width of your wall.
5. Beginning at the left hand side of your wall, peel off the A.I.M.™ strip backing and apply to the wall. Apply strips vertically every 10 inches apart. Finish with an A.I.M.™ strip at the far right hand side even if it is less than 10 inches.
6. First, determine the layout of your planks on the floor. Starting at the bottom-left hand corner, begin placing the planks perpendicular to the A.I.M.™ strips and apply pressure to ensure a tight hold.
7. When all of your planks have been placed on the wall, step back and enjoy the beauty of your reclaimed wood Artis Wall™.

REMOVAL

STEP BY STEP

1. To remove, simply slide your fingers along the top edge of your Artis Wall™ planks and slowly pull away from the wall until the plank releases from the A.I.M.™ strips.
2. After the planks have been removed, peel back a corner of the A.I.M.™ strip and slowly pull along-side the wall at a 45 degree angle.
3. After all of the A.I.M.™ strips have been removed your wall will look just as it did before Artis Wall™ was installed. No mess, no damage, just peace of mind.