



<u>Step 1</u>

Place all parts on a soft surface to avoid any scratches or damage to the product.

Attach the Top Branches (B) to the Bottom Tree Trunk (A) by inserting the iron tube on the Highest Branches (B) into the mounting position on the Bottom Tree Trunk(A).

Note: Match-up the label "1" before inserting.

Note: Shape the tree branches before assembling.

<u>Step 2</u>

Inspect and make sure all parts are connected, locked and fully secured into position. The Artificial Plant is ready to be used.

This Artificial Plant can only be used on a flat, level surface.