


ASSEMBLY INSTRUCTIONS

MIRROR CABINET





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions













	Diagram A	Insert Cam Bolt into hole as shown in diagram A.
	Diagram B	Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Diagram C	Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
Connect the panels together.		
ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.		
To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>		

Detail View - CABINET






Identifying the Hardware-Identify the hardware using the illustrations below.





Part List

1	 Top Panel - 1pc	2	 Side Panel Left - 1pc
3	 Side Panel Right - 1pc	4	 Mid Panel (A) - 1pc
5	 Mid Panel (B) - 1pc	6	 Bottom Panel - 1pc
7	 Rear Bar Top - 1pc	8	 Connect Bar - 1pc
9	 Mid Panel (C) - 1pc	10	 Mid Panel (D) - 1pc
11	 Mid Panel (E) - 1pc	12	 Rear Bar Bottom - 1pc
13	 Left Door Cabinet - 1pc	14	 Mid Door Cabinet - 1pc

Part List

15  Right Door Cabinet - 1pc	16  Adjustable Shelf (A) - 2pcs
17  Adjustable Shelf (B)- 1pc	18  Back Panel (A) - 2pcs
19  Back Panel (B) - 1pc	

Hardware List







A	 ø6x35mm Three in one bolts (24pcs)	B	 ø14.5x12mm Three in one lock (18pcs)	C	 ø14.5x9.5mm Three in one lock (6pcs)
D	 ø10xø5x50mm Flat head screw - 4pcs	E	 ø12x55mm Plastic stopper - 4pcs	F	 Handle (3pcs)
G	 ø5/32"x22mm Handle screw (3pcs)	H	 Damping hinge (6pcs)	I	 ø7xø3.5x15mm Flat head screw (36pcs)
J	 Laminate pad (12pcs)	K	 ø8x30mm Wood dowel (24pcs)	L	 ø6x30mm Wood dowel (12pcs)
M	 ø7xø3.5x15mm Round head screw(6pcs)				

STEP: 1


A




24PCS





Don't lean






Don't over tighten




STEP: 2


B	K	C	L
			
4PCS	4PCS	6PCS	12PCS




STEP: 3




STEP: 4



STEP: 5



STEP: 6




M




6PCS


STEP: 7

H	I
	
6PCS	12PCS





STEP: 8

F	G	I
		
2PCS	2PCS	16PCS





Use the screws to adjust up or down

Use the screws to permanent




Use the screws to adjust left or right


Use the screws to adjust in or out




STEP: 9



F	G	I
1PC	1PC	8PCS




STEP: 10




J
12PCS

STEP: 11




D	E
4PCS	4PCS




Draw the spacing between the walls and the No.8, punch holes in the wall, and fix the No.8 to the wall with screws.

Note: Appropriate distance from the top of cabinet to the ground is 74.8".


STEP: 12



STEP: 13



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

