DESIGN PURCHASE CONSTRUCT

Installation Instructions, Post Base

ENJOY

56604 4x6 (4x6-PB-LS) 51704 4x6 (4x6-PB-IW) 56605 10x10 (10x10-PB-LS) 56607 4x4 (4x4-PB-LS) 51707 4x4 (4x4-PB-IW) 56608 6x6 (4x6-PB-IW) 51708 6x6 (4x6-PB-IW) 56609 8x8 (8x8-PB-IW) 51709 8x8 (8x8-PB-IW)

this instruction illustrates 6x6 Post Base installation. All Post Bases will be installed the same.

Laredo Sunset shown



V2.00 - Installation Instructions, Specifications and Project Plans are effective May 1, 2015 and reflects information that available as of April 10, 2014. This information is updated periodically and should not be relied upon after October 15, 2016. Please visit www.OZCOBP.com to get current information.

6x6 shown with optional 2-3/8 Star (56623-sold separately)





DESIGN

PURCHASE CONSTRUCT

Laredo Sunset

Ironwood



2 great styles same functionality



Laredo Sunset

(566XX series)

ENJOY

lronwood (517XX series) choose your connection lifestyle

both styles available for most products

OV Ornamental Wood Ties



Overview-Laredo Sunset

Installation Instructions, Post Base





Overview-Laredo Sunset

Installation Instructions, Post Base





Overview-Ironwood

Installation Instructions, Post Base





Overview-Ironwood

Installation Instructions, Post Base





mount base to surface







choose fastener that suits your application

step 1

Installation Instructions, Post Base



















step 3

Installation Instructions, Post Base



Installation Instructions, Post Base





OZCO BUILDING PRODUCTS

additional instructions

- center post as shown in
- previous steps install 1 compression plate with fasteners
- remove, reposition & reinstall post/compression plate as shown with <u>plate facing wall</u> complete assembly as shown

this procedure applies to all OZCO Post Bases & Post Anchors utilizing compression plates (56607 shown)



Special Instructions-mounting next to wall

Installation Instructions, Post Base