

Installation Instructions for Camalay® Cascade Shade - US Patent No. 10,871,030

Some fabrics will need to be ironed from being shipped. After installation, if wrinkles appear, the curtain can simply be sprayed using a water spray bottle, and the wrinkles will fall out.

INSTALLATION USING ADHESIVE HOOK FASTENER

1. Clean and dry surface where the adhesive will be attached.
2. From detached piece of hook fastener strip, remove plastic backing, exposing sticky side. (SEE PICTURE 1)
3. Place above window molding or in desired position (make sure it is centered before adhering).
IMPORTANT NOTE: Adhesive hook fastener will perform better if adhered to the “lip” above the glass rather than the “ceiling” part of the window casing. **MUST BE A FLAT SURFACE** (SEE PICTURE 2)
4. Use spoon or hard object to rub against adhesive hook fastener, smoothing and removing any air bubbles.
5. For lengthened life of adhesive, let cure for 24 hours before attaching shade.
6. Attach shade to the hook fastener strip that is now above window molding. (SEE PICTURE 3)

Camalay® Cascade Shade has a 3” rod pocket to allow for hanging with a decorative curtain rod or a tension rod if desired.

OPERATING INSTRUCTIONS

1. Slip top curve of Cascade hook behind strap at the desired fold level, keeping the other three rungs in front of strap. (SEE PICTURE 4)
2. Bring bottom of shade up to second rung of Cascade hook and secure in place by slipping the back strap onto the second rung of hook. (SEE PICTURE 5)
3. Bring the now bottom of the shade up to the 3rd rung of the Cascade hook and secure in place by slipping the back strap onto the third rung of hook. (SEE PICTURE 6)
4. Fold the rest of the shade up to the bottom rung of the Cascade hook and secure in place by again slipping the back strap onto the bottom rung of the Cascade hook. (SEE PICTURE 7)

Go to www.eaststreethome.com for video hanging instructions.



PICTURE 1



PICTURE 2



PICTURE 3



PICTURE 4



PICTURE 5



PICTURE 6



PICTURE 7

