

Align gate pull position, drill pilot holes, then secure with 4 screws included.

