

AMERICAN PERMAHEDGE™

INSTALLATION INSTRUCTIONS

1. START AT ONE END, AT THE TOP OF THE FENCE.
2. SLIDE ONE PIECE DOWN VERTICALLY, WITH POINTED END DOWN.
3. SLIDE DOWN (DO NOT WEAVE) UNTIL YOU HAVE REACHED DESIRED HEIGHT, WHICH IS USUALLY JUST BELOW TOP OF FENCE.
4. CONTINUE TO INSTALL ONE PIECE AT A TIME.

