



Ultra-thin Wall Repair Patch

INSTALLATION INSTRUCTIONS

Perfect Finish™ **FibaTape®** SELF-ADHESIVE REPAIR PATCH



TIME REQUIRED: 15 minutes + dry time



SKILL LEVEL: Easy - DIY friendly

TOOLS & MATERIALS

- Wall repair patch
- Taping knife
- Joint compound
- Sanding block

PATCH SIZES:

- 4"x4" - covers holes up to 3" (7,6 cm)
- 6"x6" - covers holes up to 5" (13 cm)
- 8"x8" - covers holes up to 7" (18 cm)

INSTRUCTIONS:

1. Select patch size 1/2" larger than the hole on all sides.
2. Clean repair surface area removing any loose debris. Wipe away dust.
3. Peel away patch liner and apply patch to surface. Center patch over the hole. Press down firmly on all edges.
4. Using taping knife, apply compound. Feather around edges, concealing the patch. Allow to dry.
5. Sand repair site lightly, then apply a thin finishing coat of compound. Allow to dry.
6. Sand to a smooth finish. Additional finish coats may be applied as needed.
7. Prime and paint.

