

# Assembly Instruction Sheet #IS- 6606C32C For Style 6603C20C

**Tools Required:** Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

**Light Source:** (12) GU10 35W

**Estimated Assembly Time:** 20-30 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

## ⚠ Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture.

We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

## Package Contents



**A** Fixture Body x1

40mm\*1PCS

**B** Crystal x230

## Hardware Contents

PART	DESCRIPTION	QUANTITY
AA	Decorative Caps	4pcs
BB	Electrical Marrets	2pcs
CC	Outlet Box Screw	2pcs
DD	Mounting Screw	4pcs
EE	Mounting bracket	1pcs



## STEP 1 – Attach Mounting Screws, Lock Washers and Hex Nuts to Mounting bracket

**A.** Line up a set of holes on the Mounting bracket (EE) and Holes on the ceiling canopy.

Thread Mounting Screws (DD)

into the holes on the


Mounting bracket (EE). Pass Lock

Washers and thread Hex

Nuts onto the Mounting

Screws (DD).

Hand tighten until snug.



**Figure 1**

## STEP 2 – Attach Mounting bracket to Outlet Box


**A.** Pass the supply wires through the Mounting bracket (EE).

Attach the Mounting bracket (EE) to the Outlet Box with the head of the Green Ground Screw facing you.

Secure it with Outlet Box

Screws.

Tighten until snug.



**Figure 2**

## STEP 3 – Fit Ceiling Canopy to Mounting bracket Assembly

**A.** Fit the ceiling canopy to Mounting Screws (DD) and secure with Decorative Caps (AA). Note: The ceiling canopy should be snug against the ceiling and the Decorative Caps (AA).

If not, adjust the length of the

Mounting Screws (DD) by

unscrewing the Hex Nut

and Lock Washer and

then screwing Mounting

Screws (DD) in or out of the

Mounting bracket (EE) until the

correct length is achieved.


Once the ceiling canopy is

secure, remove the

Decorative Caps (AA)

and ceiling canopy

and proceed to Step 4.



**Figure 3**

#### STEP 4 - Wire Connections

- A. Use standard wire connectors to make all wire connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.




Figure 4

#### STEP 5 - Install Ceiling Canopy to Ceiling

- A. Carefully tuck all wires into the outlet box and position the ceiling canopy of the Fixture Body (A) over the outlet box. Align the holes in the ceiling canopy with the Mounting Screws (DD). Secure with Decorative Caps (AA) and hand tighten until snug.




Figure 5

#### STEP 6 - Install Crystal and Bulbs.

- A. Install bulbs onto sockets and push snug into place.  
B. Please put the crystal (B) to the Fixture Body (A).




Figure 6