

Align brace position, drill pilot holes, then secure with 8 screws included.

