



Aspect™ Glass Peel & Stick Tile Installation Guide

E

PROPER SURFACE PREPARATION IS ESSENTIAL FOR A SUCCESSFUL PROJECT



Failure to follow recommended surface preparation instructions may void the warranty. ACP, LLC is not responsible or liable for any labor costs or damaged product incurred as a result of improper installation. All product defects are covered under our 5-year limited warranty.



Read this installation manual in its entirety before you start. For the typical do-it-yourselfer, the installation of Aspect peel & stick tiles is a relatively easy project. There are additional tips and ideas for the design and installation of your project on our website, Aspectideas.com. If you have doubts about doing this installation, you should contact a qualified contractor, carpenter or professional installer.

Careful layout and tile application can still sometimes leave gaps between the tiles. To hide any gaps, we recommend painting the wall to which the tiles are applied before starting. Use a paint color that closely matches the tile color.

Aspect Glass Tiles allow for two easy installation methods:

Method 1: The adhesive on the back side of the Aspect tiles is engineered to stick to flat, primed, smooth walls.

Allow the tiles and substrate to come to room temperature (65 to 100 degrees F.) before installation. Use a heat gun or other source to warm the tiles and substrate if necessary.

If you are using installation Method 1, proper wall preparation is required. Aspect can be installed over most structurally sound substrates if they are clean, flat, smooth, dry, and free of dust, wax, soap scum and grease. Acceptable substrates are drywall, plaster or clean, smooth tile (glazed, porcelain type tile; not porous or textured). Any damaged, loose or uneven areas must be repaired, patched, leveled and primed. Fill cracks and irregularities with wallboard compound or spackling, then sand smooth with fine-grade sandpaper.

The substrate to which you are applying Aspect tiles must be primed with a fresh coat of latex or oil-based primer. Ingredients in "paint & primer in one" products can cause adhesion failure; as such, be sure to use a stand-alone primer. See below for Method 2 if you prefer not to prime the surface.

Due to manufacturing variations, we cannot guarantee an exact color match from lot to lot. Prior to adhering Aspect tiles to your wall, please unpackage & lay out all purchased product to ensure color consistency. If you encounter unreasonable color variation, please give us a call at 1-800-434-3750 (7am-4:30pm CST, M-F) so that we may assist you with your project.



Method 1

The adhesive on the back of the Aspect tiles is extra sticky and pressure sensitive.

Occasionally, even after properly preparing the substrate, the surface can still have bows, high spots, ridges or uneven areas. One way to test the area of the substrate where the tile is to be applied is to place a tile (with the back liner unpeeled) on the area to see if it "rocks" or if it has a solid, flat foundation. If proper adhesion is difficult or impossible, a recommended adhesive can be applied to the back of the tile to allow good adhesion. See Method 2 below for more information.